



General Safety Guidelines

By following these simple guidelines you will reduce the risk of injury while operating the pwc with the Extractor Sled..

1. To ensure that this device is properly used, this device should be operated ONLY by personnel who have had proper training for its use, through a training program recommended by Extractor.
2. Inspect all sled components and attachment hardware or fasteners for proper connection to craft; and, make sure everything is in safe operating condition by conducting a pre-operation check.
3. Keep all hands, feet, and heads away from the hitch attachment area while sled is in use. Only use provided hand grips for the purposes of riding on the sled. Make sure protective boot covering is fastened to attachment points while Quick Hitch version sled is mounted on the pwc and in use.
4. Use all approved personal protective equipment as mandated by law and/or recommended by personal watercraft manufacturers for operating or riding as passengers (ie. helmets, eye protection, neoprene gloves, booties, wetsuits or dry suits, approved flotation vests.) It is recommended that people riding sled in surf, rivers, or in highly dynamic or possibly dangerous conditions wear approved head, eye, and face protection, as well as personal flotation devices.
5. Do not stand on sled while in operation. Only ride sled in the kneeling or prone positions.
Those riding on sled should keep their body weight balanced in the middle of the sled. Leaning in the direction of turns enhances turning performances made by pwc operator. Weight distributed too far forward or too far back may cause performance problems for pwc and may cause pwc to lose control in high speed applications, thus causing possible injury to those on sled.
6. Use good judgement while operating pwc and sled. Use this sled only in environments of which you have been trained. Do not use this device in an environment or in conditions deemed to pose certain death or injury to rescue personnel. Remember, the passengers on this sled are dependant on the safe operations of the pwc operator or pilot.
Check with local laws governing the operation and use of the sled with passengers prior to its use.

Recommended safe speeds: 35MPH. (50 KPH) Or less

Maximum Capacity: 4 persons or 600lbs.(270Kg.) For Full Size Extractor

2 persons or 400lbs. (180 Kg.) For Extractor Junior, Extractor P.R.O.